

## Progress Hybrid Door Latch Adjustment

**Please read all the instructions before you begin the procedure.** Confirm that you have all the necessary tools and materials. If you have any questions, technical support is available toll free at 1-800-866-4344, Monday-Saturday 9:00 – 5:00 ET

### Tools Needed:

- 5/32" hex key
- Flat blade screwdriver
- 7/16" open end wrench
- 3/16" hex key

1. Make sure the stove is cool.
2. Remove the loading door by pushing the top and bottom hinge pins up and out of the door frame while supporting the door. Lift the door up and out of the door frame. There will be a washer between the lower door hinge and door frame.



3. Lay the door, stone side down on a flat surface. Remove the four allen head bolts with a 5/32" hex key.



4. Separate the body of the door from the stone and retainer. (The stone may stay with the door)
5. Use a 3/16" hex key to tighten the door latch bolt while holding the lock nut with a 7/16" wrench. (Note: some doors may have a slotted bolt to secure the door latch. Use a flat blade screwdriver to tighten the bolt.) The latch should move freely but firmly.



6. Lay the body of the door over the stone and retainer. Align the holes in the body with the holes in the retainer and secure the parts with the four allen head bolts. Do not over tighten the bolts.
7. Return the assembled door to the stove. Align the bottom hinge pin with the hole in the bottom of the door frame first, then insert the top hinge pin. Be sure the washer is in place on the lower door frame hinge. Insert the top hinge pin.

**We need your help!** Woodstock Soapstone Co. takes great pride in providing the highest quality products as well as the best customer service in our industry. We welcome your suggestions and input to help us achieve these goals. If you have any comments to improve our products, service, and information provided in these instructions please contact us at (800) 866-4344 or [info@woodstove.com](mailto:info@woodstove.com). Thank you.

Revised 2/20/13